

Instruction for Vector Optics Tsyklon 4x32 Riflescope



WARNING: NEVER LOOK AT THE SUN THROUGH THE RIFLESCOPE (OR ANY OTHER OPTICAL INSTRUMENT). IT MAY PERMANENTLY DAMAGE YOUR EYES.

EYEPIECE FOCUSING

The eyepiece is designed to provide a precise fast focus at certain eye relief. The eyepiece will focus faster than your eye can compensate for any inaccuracy in your adjustment.

MOUNTING

The riflescope is installed on gun by means of a pair of weaver or dovetail mount rings. Use qualified mount with base designed to fit your particular rifle. The riflescope shall be mounted as low as possible without touching either the barrel or the receiver.

For safety reasons, allow at least 3 inches of clearance between the riflescope and your eyes when shooting. Slide riflescope forward or backward to acquire the proper eye relief that allows you to see full field of view. Rotate the riflescope in the rings that the vertical crosshair is vertical and horizontal crosshair is horizontal. Then tighten all screws to fix riflescope firmly on the rifle.

Do not over tighten the mount rings. It may lead to damage to the riflescope and mount.

ZEROING

Tsyklon riflescope features finger-adjustable audible-click elevation and windage adjustments. Elevation is the vertical (up-and-down) adjustment, usually on the top of the riflescope. Windage is the horizontal (left-to-right) adjustment, usually on the right of the riflescope.

The scopes feature 1/2 M.O.A (Minute of Angle) windage and elevation adjustment with audible clicks, meaning that 1 click moves the point of impact 1/2 inch at 100 yards.

With the riflescope mounted, rest the firearm onto a solid support and aim at a target 100 yards away. Slowly shoot a small 3 to 5 round test group onto your target. Adjust windage & elevation screws in the direction you want to move the bullet impact. Each click of adjustment moves the point of impact. Shoot another 3 to 5 round test group. Repeat until you are satisfied with the point of aim.

SEALED, WATERPROOF AND FOGPROOF

The riflescope is nitrogen-purged to remove any vestige of internal moisture, also has O-ring to prevent the entry of dust or moisture.

MAINTENANCE

Your riflescope, though amazingly tough, is a precision instrument that deserves reasonable cautious care.

- When cleaning the lens, first blow away any dirt and dust, or use a soft lens brush. Fingerprints and lubricants can be wiped off with lens tissue, or a soft clean cotton cloth, moistened with lens cleaning fluid.
- All moving parts of the riflescope are permanently lubricated. Do not try to lubricate them.

